

# ADDITIONAL SAFETY INSTRUCTIONS

This document is part of the device.

**BE SURE TO READ THESE INSTRUCTIONS BEFORE OPERATING THE DEVICE  
ONLY USE THE DEVICE AFTER READING ALL THE INSTRUCTIONS  
INSTRUCTIONS SUPPLIED WITH THE PRODUCT.**

## INSTALLATION AND ASSEMBLY

- For installation and use only in the manufacturer's approved enclosure.
- Place the appliance only on level, stable surfaces.
- For wall-mounted models, install the appliance only on non-combustible walls.
- Do not use in bathrooms, bedrooms or any room used for sleeping.
- Comply with all building regulations when using the appliance.
- Do not use in draughts.

## SERVICE AND POURING

- Never fill the appliance with fuel while it is running or hot. Ensure that the container is cold.
- Always allow the combustion chamber to cool down completely.
- Only start the device once the combustion chamber has cooled down.
- Stay safe and exercise caution when pouring biofuel.  
Do not start the device if fuel has spilled outside the combustion chamber.
- When filling the tank with fuel, never exceed the level indicated by 'max'.  
If fuel spills, wipe it up and wait for the excess to evaporate before lighting the fire.
- Never transport fuel in containers other than the original ones.
- Store fuel at room temperature in a separate location, away from this appliance or other fuel containers.

## FIRE AND TEMPERATURE SAFETY

- Hot surfaces – do not touch the combustion chamber or the device casing, when the flame is burning, as they may be hot. Keep children and pets away.
- Do not place or install anything near the appliance that could be susceptible to high temperatures from fire.
- Keep a distance of 1 metre from flammable materials such as newspapers, curtains, blankets, cushions, etc.
- Decorative logs (imitation wood) that could be damaged or moved by the wind must not be used.

## GENERAL TERMS OF USE

- Use only in well-ventilated areas.
- Always use the appliance with the door open.
- Do not use the appliance for cooking, heating food or heating water.
- Do not use any other products with this device that have not been approved for use.
- Do not operate the device without all the components and steps described in the manual.
- Do not start the device if anything has fallen into the container or is inside it.
- Do not put anything into the container before or during operation.
- Keep children and animals away from the device when it is in operation.
- Do not use the device in areas where flammable vapours may be present.
- Do not use in rooms where oxygen cylinders are present.
- Do not allow other persons to operate the device without reading the operating instructions and safety instructions.
- Keep the user manual.

## THREATS AND PREPAREDNESS

- Improper use may result in an uncontrollable fire.
- Use common sense when operating the device, as it involves real fire.
- Never use petrol, oil, kerosene or any other fuel other than that intended for use with this appliance.
- We recommend keeping a Class B fire extinguisher near the appliance.
- In case of fire: Exit quickly and alert others. Call the fire brigade.  
Do not move the appliance, attempt to extinguish the fire, or pour water on it.